

MANUAL



WiFi-Enabled

Infrared Heater

With Inbuilt LED Display


Please refer to this manual for assistance with setting up and getting the most out of your WiFi-enabled LED fireplace heater.

THANK YOU FOR YOUR PURCHASE

CONTENTS

PAGE 3 - 8	INSTALLATION
PAGE 8	OPERATION
PAGE 9 - 10	HOW TO SET THE TIME
PAGE 10 - 12	HOW TO PAIR TO THE APP
PAGE 13	APP DISPLAY
PAGE 14 - 15	HOW TO MANUALLY PAIR TO THE APP
PAGE 15	FAQ / TROUBLESHOOTING,
PAGE 16	APP FUNCTIONS, CONTROLLER FUNCTIONS, TECHNICAL DATA

PARTS FOR INSTALLATION



1x Heater




**3x Screw
(M4.8*50mm)**




**3x Expansion
Plugs**



**1x Screw
(M4.8*40mm)**




**1x Screw
(M3*16mm)**



**1x Bottom Mounting
Bracket**



1x Manual




1x Baffle




**2x Screw
(M3.5*9.5mm)**

INSTALLATION


STEP 1



STEP 2




STEP 3




STEP 4


SCREW
(M4.8*50mm)




STEP 5




STEP 6




STEP 7




STEP 8



MINIMUM MOUNTING DISTANCES



OPERATION




NOTES


- 1 When powered on and in standby, 'OFF' will appear on the LCD screen.
- 2 The temperature sensor can be found at the bottom of the heater to the right, ensure it is not damaged in any way.
- 3 To set customisable time slots, you must connect to the SmartLife app.

HOW TO SET THE TIME


STEP 1




STEP 2



STEP 3




STEP 4




STEP 5

HOLD TO
PROGRESS TO
SETTING THE
DAY



STEP 6

ADJUST THE
DAY
(MON - SUN)



HOW TO PAIR TO THE APP

BEFORE YOU START

- 1 The SmartLife app is compatible with IOS and Android.
- 2 You cannot control the heater from the app without first pairing to the remote.
- 3 The app is only compatible with 2.4GHz networks.


STEP 1

DOWNLOAD



STEP 2

PRESS DOWN
TOGETHER FOR
3 SECONDS





PLEASE NOTE


- 1 Holding down the **POWER** and **▲** buttons for 10 seconds will make the heater enter WiFi pairing mode, so it will now appear on the SmartLife app - **AS SEEN IN STEP 4**

STEP 3


PRESS




STEP 4



STEP 5



APP DISPLAY




NEED HELP?


- 1 The app will let you control your heater from anywhere as long as it is connected to WiFi/mobile data
- 2 If your heater doesn't appear on the SmartLife app, you may need to search for it manually:

HOW TO MANUALLY PAIR TO THE APP

STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



IF YOU HAVE ANY TECHNICAL ISSUES OR IF YOU HAVE ANY QUESTIONS WHILST SETTING UP YOUR WIFI PANEL, PLEASE GET IN TOUCH.

FAQ / TROUBLESHOOTING

WHY CAN'T I CONNECT TO THE APP?

- 1 The heater must be somewhere with a secure connection to WiFi.
- 2 The app is only compatible with 2.4GHz networks and will not work with a 5GHz signal. If you have a mixed network, your network provider will be able to separate them for you.
- 3 Ensure your heater is near your WiFi router when first connecting to the app.

DOES THE APP OR CONTROLLER HAVE PRIORITY?

- 1 Neither the app or controller has priority over the other. Your heater will pay attention to the most recent input, whether on the remote or on the app.
- 2 Updating the target temperature with the controller will update the app's display.
- 3 Updating the target temperature with the app will not update the controller's display even though the change has been registered.

APP FUNCTIONS

- 1 The app uses the temperature sensor built into the bottom of the heater, so ensure it is not damaged.
- 2 The  icon can be used to customise the name of your heater and group heaters together.
- 3 The app can be used for more in-depth programming in the 'Create Scene' option.

CONTROLLER FUNCTIONS

- 1 Pressing and holding the **POWER** button will let you change between the temperature-based heating mode and a timer to dry towels.
- 2 Pressing and holding the ▲ and ▼ buttons together will change the display between °C and °F.

TECHNICAL DATA

Voltage	220 - 240V/50Hz
Heating element	Graphene Carbon
Wavelength	8-14μ
Surface temperature	60°C - 80°C
Electricity efficiency	98.5%
Life expectancy (hours)	75,000
Surface material	Strengthened Glass
IP rating	IPX4
Overheat protection	Yes
Power cord length	1.8m + UK Plug
Installation	Wall

THIS MANUAL IS APPLICABLE FOR:

DFP700W, DFP1300W