

MANUAL



IP65-Rated

Mid Infrared Heater

With Freestanding Arch

Please refer to this manual for assistance with setting up and getting the most out of your freestanding arch heater.

THANK YOU FOR YOUR PURCHASE

CONTENTS

PAGE 3

GET TO KNOW YOUR HEATER


PAGE 4 - 7

SETTING UP YOUR HEATER

PAGE 8




TECHNICAL DATA

GET TO KNOW YOUR HEATER




SETTING UP YOUR HEATER

STEP 1




Connection point 1


STEP 2




STEP 3



STEP 4




#2




Base of heater

STEP 5




#3



Rear of heating element

#4




Rear of heating element

TECHNICAL DATA

Wattage	2500W
Voltage	220-240/50Hz
Heating element	Gold lamp
Wavelength	3-8μ
Surface temperature	200°C - 400°C
Electricity efficiency	98.5%
Life expectancy (hours)	5,000
Surface material	Metal
IP rating	IP65
Overheat protection	Yes
Power cord length	6m + UK plug
Installation	Freestanding

HEAT SPREAD



THIS MANUAL IS APPLICABLE FOR:

ARCH2500