


IP65 Mid Infrared Heater

Safety Instructions and Operation Manual



Thank you for purchasing this product. Please read all instructions carefully before using the device and strictly follow the instructions in this manual. The "**Important Safety Instructions**" section details how to use this product as intended and as safely as possible. Please ensure that you keep this manual to hand for future reference.

Brief Introduction

This product is an IP65 rated infrared bar heater. It can be used for any number of outdoor applications, such as smoking areas, courtyards, lounge sets, etc. This heater is energy efficient, convenient and environmentally friendly.

Important Safety Instructions

When using electrical appliances, always follow basic safety precautions to reduce the risk of fire, electric shock or injury. Read all the following instructions before using this heater:

- This heater is hot when in use. To avoid burns, do not touch it with bare skin while in use. Keep combustible materials, such as furniture, pillows, bedding, paper, clothes and curtains at least 0.9m away from the heater.
- Take extreme caution when the heater is left powered on unattended and whenever using the heater in the presence of children.
- Always unplug the heater when not in use.
- Do not operate the heater with a damaged cord/plug, after the heater has malfunctioned or after the heater has been dropped/damaged in any manner. If you experience any of the previously listed events, discard the heater or return it to an authorised service facility for examination and/or repair.
- This heater is not intended for use in bathrooms, laundry areas or any similar locations. Never position the heater where it may fall into any kind of water container.
- Do not run the cord under any carpeting. Do not cover the cord with throw rugs, runners or similar coverings. Do not leave the cord under any furniture or appliances. Position the cord away from busy areas to prevent tripping over.
- Only plug the heater into properly grounded outlets.
- To disconnect the heater, turn off the power button, then remove the plug.
- Do not allow foreign objects to enter any ventilation or exhaust openings as this may cause an electric shock, fire, or damage to the heater.
- Do not block any ventilation. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Do not use the heater in areas where gasoline, paint, or flammable liquids are present.
- Only use the heater as established here. Actions not recommended may result in fire, electric shock or injury.

- Always plug the heater into a wall outlet/receptacle directly. Never use an extension cord or relocatable power tap (outlet/power strip.)
- Check if the voltage indicated on the nameplate corresponds with the local mains voltage before connecting the heater.
- The heater must never be placed directly below a mains socket.
- The casing and the front cover of the appliance become extremely hot during operation. Ensure that no combustible material covers or obstructs the heater, whether due to wind or any other influences (such as curtains, marquees, flags, plastic foil etc.)
- If the heater needs any kind of repair, turn it off and unplug it. Do not try to repair the heater by yourself. Please contact a suitable qualified electrician for maintenance.
- Remove the plug from the socket and wait until the heater has sufficiently cooled off before cleaning it.
- Children aged 8 and older, or persons with reduced capabilities, may use this heater if supervised or instructed on safe use and hazards . Children must not play with the heater.

SPECIFICATIONS

Name	☐ Twilight
Voltage (V)	☐ 220V-240V~
Power consumption (W)	☐ 3X1000W
Dimensions L×W×H (mm)	☐ 730×640×170
Weight (kg)	☐ 2.8KG
IP code	☐ IP65
Infrared projection angle	☐ 60°±5°

Operating Instructions

- Remove all packaging and check for any signs of damage.
- The heater must be mounted at a minimum of 1.8 metres.
- The heater must be a minimum of 25cm below any covers and must be a minimum of 50cm away from any kind of walls.
- It is recommended that you mount the heater at a 45° downward-facing angle.
- Ensure the heater is not in an area prone to excessive wind.
- When not using the stand, fix the mounting bracket to the ceiling first. Ensure it is installed in a secure spot.
- Adjust the positioning of the heater and tighten all screws. Regularly check the firmness of all screws as they can loosen from weathering.
- Power the heater on and operate it for 15 minutes to ensure it works as intended.
- When the heater is not being used, unplug it at the socket.

Figure1





Figure2



Adjust the positioning before installing.

Cleaning and Maintenance

- This appliance has a robust, maintenance-free aluminium casing with a protective toughened glass cover. There are no serviceable parts.
- Before cleaning, remove the plug from the power outlet and wait until the heater has sufficiently cooled.
- Only wipe the heater with a clean lint-free cloth or a soft brush.
- Never use abrasive cleaners, scrubbing brushes or chemical cleaners to clean the heater.
- Alcohol cleaners are suitable for cleaning the heater.
- To protect against electrical shock and danger of life, do not immerse any part of the heater in any liquids.
- If the heating element needs to be replaced, please contact the manufacturer.
- For any other service, please contact a suitable qualified electrician.

Disposal



This symbol indicates that the appliance cannot be disposed of domestically but must be handed to a collection point for recycling electric and electronic appliances. Information concerning where the equipment can be disposed of can be obtained from your local authority.

Customer Service

- Repairs must only be carried out by a qualified electrician, thus ensuring electrical safety.
- Improper maintenance could endanger the heater and user.
- Your warranty does not cover damage or failure resulting from alteration, accident, misuse, abuse, neglect or improper maintenance.