

# IP65 Mid Infrared Heater

## Safety Instructions and Operation Manual

(Note: Do not cover this product with any material while powered on)



- Children aged 8 and older, or persons with reduced capabilities, may use this heater if supervised or instructed on safe use and hazards . Children must not play with the heater. Children may only clean or perform maintenance on the heater when under supervision.
- If the power cord is damaged, it must be replaced.
- Children aged 3 years or below should be kept away unless constantly supervised.
- This product can become very hot and cause burns. Take care when operating around children and vulnerable people.  
There is no temperature control device for this heater. Do not use this heater indoors.
- Never place the heater directly below a mains socket.  
The casing and the front cover become extremely hot, ensure no combustible materials cover or obstruct the appliance.

## Brief Introduction

This product is an IP65 rated infrared heater. It can be used for any number of outdoor applications, such as smoking areas, courtyards, lounge sets, etc and can be used indoors. This heater is energy efficient, convenient and environmentally friendly.

## Important Safety Instructions

When using electrical appliances, always follow basic safety precautions to reduce the risk of fire, electric shock or injury. Read all the following instructions before using this heater:

- This heater is hot when in use. To avoid burns, do not touch it with bare skin while in use. Keep combustible materials, such as furniture, pillows, bedding, paper, clothes and curtains at least 0.9m away from the heater.
- Take extreme caution when the heater is left powered on unattended and whenever using the heater in the presence of children.
- Always unplug the heater when not in use.

- Do not operate the heater with a damaged cord/plug, after the heater has malfunctioned or after the heater has been dropped/damaged in any ,manner. If you experience any of the previously listed events, discard the heater or return it to an authorised service facility for examination and/or repair.
- This heater is not intended for use in bathrooms, laundry areas or any similar locations. Never position the heater where it may fall into any kind of water container.
- Do not run the cord under any carpeting. Do not cover the cord with throw rugs, runners or similar coverings. Do not leave the cord under any furniture or appliances. Position the cord away from busy areas to prevent tripping over.
- Only plug the heater into properly grounded outlets.
- To disconnect the heater, turn off the power button, then remove the plug.
- Do not allow foreign objects to enter any ventilation or exhaust openings as this may cause an electric shock, fire, or damage to the heater.
- Do not block any ventilation. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Do not use the heater in areas where gasoline, paint, or flammable liquids are present.
- Only use the heater as established here. Actions not recommended may result in fire, electric shock or injury.
- Always plug the heater into a wall outlet/receptacle directly. Never use an extension cord or relocatable power tap (outlet/power strip.)
- Check if the voltage indicated on the nameplate corresponds with the local mains voltage before connecting the heater.
- The heater must never be placed directly below a mains socket.
- The casing and the front cover of the appliance become extremely hot during operation. Ensure that no combustible material covers or obstructs the heater, whether due to wind or any other influences (such as curtains, marquees, flags, plastic foil etc.)
- If the heater needs any kind of repair, turn it off and unplug it. Do not try to repair the heater by yourself. Please contact a suitable qualified electrician for maintenance.
- Remove the plug from the socket and wait until the heater has sufficiently cooled off before cleaning it.
- The heater must only be mounted by an authorised specialist.

# Save These Instructions


## Specifications

Name	<input type="checkbox"/> Vesta
Voltage (V)	<input type="checkbox"/> 220-240V~ 50Hz
Power Consumption (W)	<input type="checkbox"/> 2000W
IP Code	<input type="checkbox"/> IP65
Infrared Projection Angle	<input type="checkbox"/> 60°±5°

## Operation Instructions

- Remove all packaging and check the heater, power cord and plug for damage.
- Never move the heater while in use.
- Pay attention to where the heater is mounted and all relevant materials (dowels, screws etc.) Ensure they are stable and suitable for long-term use.
- Ensure the heater is not mounted in an area with excessive winds.
- Plug in the cable and operate the heater for 15 minutes and ensure the heater works as intended.

Figure2



Adjust the positioning before installing.

## Cleaning and Maintenance

- This appliance has a robust, maintenance-free aluminium casing with a protective toughened glass cover. There are no serviceable parts.
- Before cleaning, remove the plug from the power outlet and wait until the heater has sufficiently cooled.
- Only wipe the heater with a clean lint-free cloth or a soft brush.
- Never use abrasive cleaners, scrubbing brushes or chemical cleaners to clean the heater.
- Alcohol cleaners are suitable for cleaning the heater.
- To protect against electrical shock and danger of life, do not immerse any part of the heater in any liquids.
- If the heating element needs to be replaced, please contact the manufacturer.
- For any other service, please contact a suitable qualified electrician.

## Disposal



This symbol indicates that the appliance cannot be disposed of domestically but must be handed to a collection point for recycling electric and electronic appliances. Information concerning where the equipment can be disposed of can be obtained from your local authority.

## Customer Service

- Repairs must only be carried out by a qualified electrician, thus ensuring electrical safety.
- Improper maintenance could endanger the heater and user.
- Your warranty does not cover damage or failure resulting from alteration, accident, misuse, abuse, neglect or improper maintenance.